

A Method for Atomic Layer Deposition of Complex Oxide Thin Films

Brian R. Beatty

M.S. Thesis in Materials Science and Engineering

Drexel University, Philadelphia, PA

11th December, 2012





Outline

- Objectives
- Atomic Layer Deposition
- Thin Film Growth
- Characterization Methods
- Results
- Conclusions



Outline



Objectives



Atomic Layer Deposition



Thin Film Growth



Characterization Methods



Results



Conclusions



Project Objectives

- Develop method for identifying best candidate precursors for depositing complex oxide films
- Determine optimal deposition parameters to obtain desired film stoichiometry
- Characterization of various film properties, for use in further optimizing subsequent depositions
- Successful deposition of desired material:
Perovskite Lead Titanate (PbTiO_3)



Outline



Objectives



Atomic Layer Deposition



Thin Film Growth



Characterization Methods



Results



Conclusions




What is ALD?

- Chemical deposition method, similar to CVD
- Separation of deposition reaction into metal chemisorption and subsequent oxidation
- Restricts reactions to surface-vapor interactions, no vapor-vapor reactions possible




Atomic Layer Deposition






Atomic Layer Deposition






Atomic Layer Deposition






Atomic Layer Deposition





Atomic Layer Deposition







Atomic Layer Deposition



Advantages

- Ultra-high film thickness resolution (\AA -level)
- High film conformality (3D structure coating)
- Lower deposition temperatures
- Potentially lower environmental/economic impact



Disadvantages

- Slow deposition rates
- Precursor chemistry is often difficult and complex (organometallic compounds)
- Many material systems lack developed ALD processes



Where is ALD used?

- Integrated Circuits: Transistor Gate Oxides (high-k)
- Alternative Energy: Low tolerances for layer thickness, high film uniformity across surface
- Biomedical: Uniform coating of highly porous structures



Outline



Objectives



Atomic Layer Deposition



Thin Film Growth



Characterization Methods



Results



Conclusions

Thin Film Growth: Film Precursors

Titanium Precursor

Titanium(IV) tetraisopropoxide:
 $\text{Ti}-\text{o}-i-\text{Pr}$

Oxidizer

- H_2O and O_2/O_3 mixtures commonly used in literature
- O_2/O_3 was chosen for higher compatibility with Pb precursors

Lead Precursors

1. Bis(2,2,6,6-tetramethyl-3,5-heptanedionato) Lead(II): $\text{Pb}(\text{TMHD})_2$
2. Lead(II) hexafluoroacetylacetonate: $\text{Pb}(\text{HFAc})_2$



Thin Film Growth: Substrates

- 200 nm $\text{SiO}_2/\text{Si}(100)$
 - ▶ 200 nm of thermally grown silica on crystalline silica.
 - ▶ Amorphous top layer
- 15 nm $\text{Pt}(111)/200 \text{ nm } \text{SiO}_2/\text{Si}(100)$
 - ▶ 15 nm of ALD-grown platinum on the $\text{SiO}_2/\text{Si}(100)$ substrate
 - ▶ Metallic (crystalline) top layer
- $\text{SrTiO}_3(100)$
 - ▶ Single crystalline oriented strontium titanate wafer.



Thin Film Growth: Deposition Parameters

- Growth Temperature
- Precursor Dosage
- Purge Time
- Precursor Exposure
- Post-Deposition Annealing



Outline



Objectives



Atomic Layer Deposition



Thin Film Growth



Characterization Methods



Results



Conclusions



Characterization Methods: Thermal Analysis



Thermogravimetric Analysis

- Method for analyzing mass loss rates as function of temperature
- Useful for determining optimal evaporation temperatures
- Can indicate multi-step evaporation/chemical conversion



Differential Calorimetry

- Allows insight into energetic transformations as a function of temperature
- Indicates phase changes, evaporation energies, and structural changes
- Useful for analyzing the stability of precursors at desired temperatures




X-Ray Fluorescence Spectroscopy (XRF)

- Similar to EDXS but uses X-rays in place of energetic electrons
- Much lower noise floor (no Bremsstrahlung radiation)
- Capable of quantitative compositional analysis of ultra-thin films



Characterization Methods: Composition Analysis






Ellipsometry

- Non-destructive optical film analysis method
- Capable of determining numerous optical/electronic parameters of film
- Primarily used to determine post-deposition film thicknesses and thus growth rates



Characterization Methods: Film Growth Rates





X-Ray Diffractometry (XRD)

- Standard technique used to identify materials and phases/orientations
- Analysis produces information about presence of particular lattice spacings
- Identifying lattice spacings (via databases or previous studies in literature) can indicate presence and orientation of specific materials and phases



Outline



Objectives



Atomic Layer Deposition



Thin Film Growth



Characterization Methods



Results





Conclusions



Results: Thermal Analysis


DSC Cycles of $\text{Pb}(\text{HFAC})_2$ and $\text{Pb}(\text{TMHD})_2$





Results: Thermal Analysis



High-Temp. DSC Cycle of $\text{Pb}(\text{TMHD})_2$





Results: Thermal Analysis



TGA Traces for $\text{Pb}(\text{HFAc})_2$





Results: Thermal Analysis



TGA Traces for $\text{Pb}(\text{TMHD})_2$





Results: Thermal Analysis

Constant Temperature Studies of $\text{Pb}(\text{HFAC})_2$ and $\text{Pb}(\text{TMHD})_2$






Results: Deposition and Processing Parameters

Temp. (°C)	Run #	Pb:Ti Ratio	Cycles	Subs. Type	Annealing	
					Temp. (°C)	Time (min)
225	20	3:1	200	Si	N/A	N/A
				Pt-Si	650	90
				STO	650	90
	21	3:1	150	Si	N/A	N/A
				Pt-Si	650	90
				STO	650	90
	22	3:1	150	Si	N/A	N/A
				Pt-Si	650	90
	28	3:1	120	STO	650	90



Results: Film Growth Rates





Results: Film Growth Rates

Run #	Subs. Type	Thickness (nm)	Growth Rate ($\text{\AA}/\text{cycle}$)
20	Si	71.8	3.59
	Pt-Si	64.4	3.22
	STO	73.6	3.68
21	Si	53.2	3.54
	Pt-Si	45.8	3.05
	STO	52.9	3.53
22	Si	53.3	3.55
	Pt-Si	46.5	3.10
28	STO	41.0	3.42




Results: Composition Analysis

Compositions of Selected Sample Films

Run #	Substrate	Composition (%)		
		Lead	Titanium	Ti:Pb Ratio
20	SiO ₂	56.6	43.4	0.769
	Pt-Si	51.5	48.5	0.944
21	SiO ₂	69.6	30.4	0.437
	Pt-Si	56.1	43.9	0.783
22	SiO ₂	67.7	32.3	0.478
	Pt-Si	56.1	43.9	0.784
24	SiO ₂	69.0	31.0	0.450
	Pt-Si	62.2	37.8	0.609




XRD of 20 on Pt-Si






XRD of 23 on Pt-Si





XRD of 28 on STO(100)





Outline



Objectives



Atomic Layer Deposition



Thin Film Growth



Characterization Methods



Results



Conclusions



Conclusions

- A procedure for identifying best precursor compounds for ALD deposition of oxides was created
- A method for designing and implementing an ALD process for a novel material has been developed
- Successfully deposited thin films containing the target material: perovskite PbTiO_3
- Films contain significant amounts of impurity phases



Conclusions: Future Work

- Refine process to maximize phase purity and film epitaxy
- Characterize ferroelectric character of crystallized films
- Investigate doping of thin films (e.g. $\text{PbZr}_x\text{Ti}_{1-x}\text{O}_3$)
- Apply process to other oxide families (e.g. BaSrTiO_3)

Questions?



Cauchy Model as used by WVASE32

$$n(\lambda) = A_n + \frac{B_n}{\lambda^2} + \frac{C_n}{\lambda^4} + \dots \quad (1a)$$

$$\kappa(\lambda) = A_\kappa e^{B_\kappa \left(\frac{hc}{\lambda}\right) - C_\kappa} \quad (1b)$$



Tauc-Lorentz Model as used by WVASE32

$$\epsilon_1 = \frac{2}{\pi} P \int_{E_g}^{\infty} \frac{\xi \epsilon_2(\xi)}{\xi^2 - E^2} d\xi \quad (2a)$$

$$\left\{ \begin{array}{ll} \epsilon_2(E) = \frac{AE_0C(E - E_g)^2}{(E^2 - E_0^2)^2 + C^2E^2} \cdot \frac{1}{E} & E > E_g \quad (2b) \\ \epsilon_2(E) = 0 & E \leq E_g \quad (2c) \end{array} \right.$$



Ellipsometry Analysis Procedure

1. High- λ Cauchy Model
2. Direct Calculation of n and κ
3. Conversion to Oscillator Model
4. Refinement of Oscillator Layer Parameters



- High- λ Cauchy Model
 - ▶ Used to determine layer thickness
 - ▶ Cauchy model applied to transparent region of film ($>600\text{nm}$)



- Direct Calculation of n and κ
 - ▶ Numeric calculation of n and κ from Fresnel equations
 - ▶ Used to provide a starting point to base Tauc-Lorentz oscillator model upon
 - ▶ Calculated values are non-physical



- Conversion to Oscillator Model
 - ▶ Data set of n and κ are used to approximate initial guesses for T-L oscillator parameters



Ellipsometry Analysis Procedure

- Refinement of Oscillator Layer Parameters
 - Software optimization of model parameters





Model Parameters for 20-Pt/Si

Layer	Variable	Thickness (nm)	Value
3. T-L Osc.		75.6	
	ϵ_1 offset		3.62
	Amp		36.54
	E_n		4.51
	C		1.30
	E_g		2.07
2. Pt		15.1	
1. SiO ₂		1.1	
0. Si		Substrate	



Ellipsometry Data from 20 - Pt/Si







Model Parameters for 20-Pt/Si

Layer	Variable	Thickness (nm)	Value
1. T-L Osc. (2)		49.2	
	ϵ_1 offset		1.42
	Amp ₁		64.71
	E _{n1}		3.69
	C ₁		4.44
	E _{g1}		1.55
	Amp ₂		1.55
	E _{n2}		2.12
	C ₂		0.76
	E _{g2}		0.001
0. STO		Substrate	



Ellipsometry Data from 28 - STO





Model Parameters for 28-STO

Layer	Variable	Thickness (nm)	Value
1. T-L Osc. (2)		49.2	
	ϵ_1 offset		1.42
	Amp ₁		64.71
	E _{n1}		3.69
	C ₁		4.44
	E _{g1}		1.55
	Amp ₂		1.55
	E _{n2}		2.12
	C ₂		0.76
	E _{g2}		0.001
0. STO		Substrate	

